# Accessories

Regulators





TYPE P100C

## **Mounting Brackets**

Mounting brackets are used to mount regulators securely to the container or to the side of the building.

Mounting Brackets				
REGULATOR TYPE	BRACKET STYLE			
REGULATOR TYPE	Triangular	Bowtie		
R622, R632, R642 and R622H	P100A	P100C		
R122H, R222 and R232	P100A			
912	P100A			



TYPE 50P-2

### **Test Gauge Assemblies**

The 50 Series test gauges are used to check appliance line pressure after the regulator has been installed.

Test Gauge Assemblies								
ТҮРЕ	INLET CONNECTION	HOSE	PLASTIC	RANGE, IN. W.C. / mbar				
50-2	1/4 in. MNPT	No	No					
50P-2	Famalallasa	Yes	Yes	0 to 35 / 0 to 87				
50P-5	Female Hose	Yes	No					





TYPE P499

**TYPE P500** 

#### **Adaptor With Screen (Type P499)**

Used to convert a 1/4 in. NPT inlet on regulators such as Types 912 and 67C to an inverted flare.

## Type P500 Plug

Keeps dirt and foreign material from entering changeover assemblies. 1/4 in. Inverted Flare.

# **Type P501 Filter Assembly**

Intended for the inlet of 67C Series regulators, the Type P501 prevents foreign material from reaching the regulator's valve disc.

Adaptor with Screen			
TYPE	SIZE		
P499	1/4 in. Inverted Flare x 1/4 in. MNPT		



TYPE J542 BOTTOM CONNECTION



BACK CONNECTION

#### **Pressure Gauges**

Fisher<sup>TM</sup> offers pressure gauges with bottom or back connection for LPG service. The back connection makes a more compact assembly on installations where space is limited. All gauges have a 2 in. / 51 mm diameter face/black Terluran® plastic case.

Pressure Gauges  PRESSURE GAUGE RANGE, psig / bar									
Bottom	1/4	J500	J501	J502	J504	J506	J542 <sup>(1)</sup>		
Back	1/4	J510	J511	J512	J514	J516	N/A		



